
DI60F-01

# **Air Mix Damper Control Servomotor Circuit**

## **CIRCUIT DESCRIPTION**

The air mix damper control servomotor is controlled by the A/C control assembly and moves the air mix damper to the desired position.

## **WIRING DIAGRAM**



## INSPECTION PROCEDURE

1∏

Actuator check.

#### **PREPARATION:**

Connect[the[hand-held[tester[to[the[DLC3.

#### **CHECK:**

- (a) Enter into ACTIVE TEST function of hand-held tester.
- (b) Check air mix damper operates as hand-held ester directs.

### OK:

Pattern[]No.	Air[Mix[Damper	Condition
0 -[3	0%[[Fully[closed)	Cool@air@omes@out
4 –[5	50%	
6 -[9	100%[[Fully[]pened]	Warm@air@omes@out




Proceed\_to\_next\_circuit\_inspection\_shown\_on problem\_symptoms\_table\_see\_page\_DI-674).

NG

2

Check air mix damper control servomotor.



### **PREPARATION:**

Remove air mix damper control servomotor.

#### **CHECK:**

Connect positive (+) lead to terminal 6 and negative (-) lead to terminal 7.

#### OK:

The lever turns smoothly to Hot side.

#### **CHECK:**

Connect positive (+) lead to terminal 7 and negative (-) lead to terminal 6.

## <u>OK:</u>

The lever turns smoothly to Cool side.

NG

Replace air mix damper control servomotor assembly.

OK

3 Check[harness[and]connector[between[A/C]control[assembly[and]air[mix[damper control[servomotor[assembly[See[page]]N-32).

NG

Repair or replace harness or connector.

OK

Check and replace A/C control assembly.